

TPR DMX-64 V2 TUNABLE WHITE LIGHT 120W LED FIBER OPTIC ILLUMINATOR™



DMX Programming Instructions

Manual Control

	Display	Description
	A001	4-Channel Address Code (001-512) press Enter, then press Menu
	u255	Warm White LED Brightness (000-255) Press UP or Down to adjust brightness; When you achieve desired brightness, press Enter to save. Hold Enter button for one second to display current color temperature
	c255	Cool White LED Brightness (000-255) Press UP or Down to adjust brightness; When you achieve desired brightness, press Enter to save. Hold Enter button for one second to display current color temperature
	n0	Master Dimmer 0-100 (0-100%)
	S0	Speed of Rotation of Flicker Wheel 0 Stop 1-127 Forward rotation from slow to fast 128 Stop 129-255 Reverse from slow to fast

DMX512 Channel Description

Channel Number	Display	Description
1	u55	Warm White LED Brightness 0-255
2	c255	Cool White LED Brightness 0-255
3	n0	Master Dimmer 0-100 (0-100%)
4	S0	Speed of Rotation of Flicker Wheel 0 Stop 1-127 Forward rotation from slow to fast 128 Stop 129-255 Reverse from slow to fast

DMX Address Set: Apply DMX signal to Illuminator via 5-pin XLR.

Press Menu (A001 should appear).

Press UP & Down buttons to reach desired DMX address. Press Enter to save.

